



RAM is enabled when SEL2=0 and SEL3=1  
 Address is selected by MAP1-3  
 OUT FEB2,0x -> map at 0000  
 OUT FEB2,2x -> map at 2000  
 OUT FEB2,4x -> map at 4000  
 ...  
 OUT FEB2,Ex -> map at E000  
 Page is selected by SEL0-1  
 (1 or 4 8K-pages available)  
 OUT FEB2,x8 -> Page 0  
 OUT FEB2,x9 -> Page 1  
 OUT FEB2,xA -> Page 2  
 OUT FEB2,xB -> Page 3  
 OUT FEB2,x0-x7 or xC-xF to disable the mapping

RTC/NVRAM expansion for Amstrad CPC 6128/Plus  
**PulkoTronics**  
 Sheet: /  
 File: nova.sch  
**Title: Nova 2021**  
 Size: User | Date: 2021-02-23  
 KiCad E.D.A. kicad 5.0.2+dfsg1-1

Rev: 1.0  
 Id: 1/1